



List of:
Hardware,
Accessories and
Components



irrigaglobal



www.irrigaglobal.com

List of hardware, accessories and components:

1. Solar Panel: 220 x 165mm 12V 430mA
2. Nomad Main Board
3. Battery Board – battery power supply circuit
4. Rechargeable Lithium Battery: 3.7v 2600mAh
5. Modem Board: LTE 2G/4GE
6. GPS external Antenna: 50 Ohm
7. LoRaWAN Antenna
8. Leaf Wetness Sensor
9. Air Temperature and Humidity Sensor & shelter
10. Rain Gauge sensor with mounting base: 0.2mm
11. Solar Radiation Sensor with mounting shelf
12. Wind Speed and Direction sensor: mechanical
13. Nomad Weather Station
14. Nomad Soil Station
15. Nomad Air Station
16. Water Pressure Sensor: 5-12v maximum 60psi
17. Watermark Sensor – water tension: 3.5 m cable
18. Sentek D&D Soil profile Probe, temperature and moisture: 30, 60 and 90 cm
19. GPS Board

To request a quote, please contact us:

Phone/WhatsApp: +55 55 99644-9128

Email: contato@irriga.net

